



USER'S MANUAL

SMOKE & CARBON MONOXIDE ALARM


Model SMC100



IMPORTANT! PLEASE READ CAREFULLY AND SAVE.

The warnings/limitations card and manual contains important information about your Smoke Alarm's operation. If you are installing this Alarm for use by others, you must leave this manual—or a copy of it—with the end user.

Para el manual del usuario en español, por favor visite firstalert.com



01 INTRODUCTION

Thank you for choosing First Alert® for your Smoke and Carbon Monoxide Alarm needs. You have purchased a state-of-the-art Smoke & Carbon Monoxide Alarm designed to help provide you with early warning of a smoke and/or carbon monoxide danger. Please take the time to read this manual and make the Smoke & Carbon Monoxide Alarm an integral part of your family's safety plan.

BASIC SAFETY INFORMATION

- IMPORTANT!**
 - Dangers, Warnings, and Cautions alert you to important operating instructions or to potentially hazardous situations. Pay special attention to these items.
 - This Smoke/CO Alarm is approved for use in single-family residences. It is **NOT** designed for marine or RV use.

- CAUTION!**
 - This combination Smoke/Carbon Monoxide Alarm has two separate Alarms. The CO Alarm is not designed to detect fire or any other gas. It will only indicate the presence of carbon monoxide gas at the sensor. Carbon monoxide gas may be present in other areas. The Smoke Alarm will only indicate the presence of smoke that reaches the sensor. The Smoke Alarm is not designed to sense gas, heat or flames.

- WARNING!**
 - This Smoke/CO Alarm cannot operate without working batteries. Removing the batteries for any reason, or failing to replace the batteries at the end of their service life, removes your protection, and **NEVER** ignore any alarm. See "If Your Smoke/CO Alarm Sounds" for more information on how to respond to an alarm. Failure to respond can result in injury or death.
 - The Silence Features are for your convenience only and will not correct a problem. See "Using the Silence Features" for details. Always check your home for a potential problem after any alarm. Failure to do so can result in injury or death.
 - Test this Smoke/CO Alarm once a week. If the Alarm ever fails to test correctly, have it replaced immediately! If the Alarm is not working properly, it cannot alert you to a problem.
 - This product is intended for use in ordinary indoor locations of family living units. It is not designed to measure CO levels in compliance with Occupational Safety and Health Administration (OSHA) commercial or industrial standards. Individuals with medical conditions that may make them more sensitive to carbon monoxide may consider using warning devices which provide audible and visual signals for carbon monoxide gas concentrations. For additional information on carbon monoxide and your medical condition contact your physician.

- Tools you will need:** pencil, drill with 3/16" (5 mm) drill bit, standard flathead screwdriver, hammer
- Parts of this Smoke/CO Alarm**
 - Battery compartment, install batteries here
 - Test/Silence button
 - CO Alarm LED
 - Power/Smoke Alarm LED
 - Turn this way to remove
 - Turn this way to attach
 - Mounting bracket
 - Mounting slots

02 ABOUT SMOKE ALARMS

TYPES OF ALARMS

All these Smoke Alarms are designed to provide early warning of fires if located, installed and cared for as described in the user's manual, and if smoke reaches the Alarm. If you are unsure which type of Smoke Alarm to install, refer the National Fire Protection Association (NFPA) Standard 72 (National Fire Alarm and Signaling Code) and NFPA 101 (Life Safety Code), National Fire Protection Association, One Batterymarch Park, Quincy, MA 02269-9101. Local building codes may also require specific units in new construction or in different areas of the home.

Battery (DC) operated Smoke Alarms: Provide protection even when electricity fails, provided the batteries are fresh and correctly installed. Units are easy to install, and do not require professional installation. They do not, however, provide inter-connected functionality.

AC powered Smoke Alarms: Can be interconnected so if one unit senses smoke, all units Alarm. They do not operate if electricity fails.

AC with battery (DC) back-up: will operate if electricity fails, provided the batteries are fresh and correctly installed. AC and AC/DC units must be installed by a qualified electrician.

Smoke Alarms for solar or wind energy users and battery backup power systems: AC powered Smoke Alarms should only be operated with true or pure sine wave inverters. Operating the Smoke Alarm with most battery-powered UPS (uninterruptible power supply) products or square wave or "quasi sine wave" inverters will damage the Alarm. If you are not sure about your inverter or UPS type, please consult with the manufacturer to verify.

Smoke Alarms for the hearing impaired: Special purpose Smoke Alarms should be installed for the hearing impaired. They include a visual Alarm and an audible Alarm horn, and meet the requirements of the Americans With Disabilities Act. These units can be interconnected so if one unit senses smoke, all units Alarm.

Smoke Alarms are not to be used with detector guards unless the combination has been evaluated and found suitable for that purpose.

All First Alert® Smoke Alarms conform to regulatory requirements, including UL217 and are designed to detect particles of combustion. Smoke particles of varying number and size are produced in all fires.

Ionization technology is generally more sensitive than photoelectric technology at detecting small particles, which tend to be produced in greater amounts by flaming fires, which consume combustible materials rapidly and spread quickly. Sources of these fires may include paper burning in a wastebasket, or a grease fire in the kitchen.

Photoelectric technology is generally more sensitive than ionization technology at detecting large particles, which tend to be produced in greater amounts by smoldering and flaming fires, which may smolder for hours before bursting into flame. Sources of these fires may include cigarettes burning in couches or bedding.

For maximum protection, use both types of Smoke Alarms on each level and in every bedroom of your home.

03 INSTALLATION

WHERE TO INSTALL THIS ALARM

Minimum coverage for Smoke Alarms, as recommended by the National Fire Protection Association (NFPA), is one Smoke Alarm on every floor, in every sleeping area, and in every bedroom (See "Regulatory Information For Smoke Alarms" for details on the NFPA recommendations).

For CO Alarms, the National Fire Protection Association (NFPA) recommends that a CO Alarm should be centrally located outside of each separate sleeping area in the immediate vicinity of the bedrooms. For added protection, install additional CO Alarms in each separate bedroom, and on every level of your home.


NOTE: For added protection, install an additional Smoke/CO Alarm at least 15 feet (4.6 meters) away from the furnace or fuel burning heat source where possible. In smaller homes or in manufactured homes where this distance cannot be maintained, install the Alarm as far away as possible from the furnace or other fuel burning source. Installing the Alarm closer than 15 feet (4.6 meters) will not harm the Alarm, but may increase the frequency of unwanted Alarms.

IN GENERAL, INSTALL COMBINATION SMOKE AND CARBON MONOXIDE ALARMS:

- On every level of your home, including finished attics and basements.
- Inside every bedroom, especially if people sleep with the door partly or completely closed.
- In the hall near every sleeping area. If your home has multiple sleeping areas, install a unit in each. If a hall is more than 40 feet (12 meters) long, install a unit at each end.
- At the top of first-to-second floor stairs.
- At the bottom of the basement stairs.

For additional coverage, install Alarms in all rooms, halls, and storage areas, where temperatures normally remain between 40° F and 100° F (4.4° C and 37.8° C).

RECOMMENDED PLACEMENT:



- When installing on the wall, the top edge of Smoke Alarms should be placed between 4 inches (102 mm) and 12 inches (305 mm) from the wall/ceiling line.
- When installing on the ceiling, place the Alarm as close to the center as possible.
- In other cases, install at least 4 inches (102 mm) from where the wall and ceiling meet. See "Avoiding Dead Air Spaces" for more information.

NOTE: For any location, make sure no door or other obstruction could keep carbon monoxide or smoke from reaching the Alarm.

WHERE NOT TO INSTALL THIS ALARM FOR BEST PERFORMANCE, IT IS RECOMMENDED YOU AVOID INSTALLING SMOKE/CO ALARMS IN THESE AREAS:

- In garages, furnace rooms, crawl spaces and unfinished attics. Avoid extremely dusty, dirty or greasy areas.

- Where combustion particles are produced. Combustion particles form when something burns. Avoid to avoid installing smoke poorly ventilated kitchens, garages, and furnace rooms. Keep units at least 20 feet (6 meters) from the sources of combustion particles (stove, furnace, water heater, space heater) if possible. In areas where a 20-foot (6 meter) distance is not possible—in modular, mobile, or smaller homes, for example—it is recommended the Smoke Alarm be placed as far from these fuel-burning sources as possible. The placement recommendations are intended to keep these Alarms at a reasonable distance from a fuel-burning source, and thus reduce "unwanted" Alarms. Unwanted Alarms can occur if a Smoke Alarm is placed directly next to a fuel-burning source. Ventilate these areas as much as possible.
- Within 5 feet (1.5 meters) of any cooking appliance. In air streams near kitchens. Air currents can draw cooking smoke into the smoke sensor and cause unwanted Alarms.
- In extremely humid areas. This Alarm should be at least 10 feet (3 meters) from a shower, sauna, humidifier, vaporizer, dishwasher, laundry room, utility room, or other source of high humidity.
- In direct sunlight.
- In turbulent air, like near ceiling fans or open windows. Blowing air may prevent CO or smoke from reaching the sensors.
- In areas where temperatures is colder than 40° F (4.4° C) or hotter than 100° F (37.8° C). These areas include non-air conditioned crawl spaces, unfinished attics, uninsulated or poorly insulated ceilings, porches, and garages.
- In insect infested areas. Insects can clog the openings to the sensing chamber.
- Less than 12 inches (305 mm) away from fluorescent lights. Electrical "noise" can interfere with the sensor.
- In "dead air" spaces.

AVOIDING DEAD AIR SPACES

"Dead air" spaces may prevent smoke from reaching the Smoke/CO Alarm. To avoid dead air spaces, follow installation recommendations below.

On ceilings, install Smoke/CO Alarms as close to the center of the ceiling as possible. If this is not possible, install the Smoke/CO Alarm at least 4 inches (102 mm) from the wall or corner.

For wall mounting (if allowed by building codes), the top edge of Smoke/CO Alarms should be placed between 4 inches (102 mm) and 12 inches (305 mm) from the wall/ceiling line, below typical "dead air" spaces.

On a peaked, gabled, or cathedral ceiling, install first Smoke/CO Alarm within 3 feet (0.9 meters) of the peak of the ceiling, measured horizontally. Additional Smoke/CO Alarms may be required depending on the length, angle, etc. of the ceiling's slope. Refer to NFPA 72 for details on requirements for sloped or peaked ceilings.

HOW TO INSTALL THIS ALARM

IMPORTANT!

- This combination Smoke/CO Alarm was designed to be mounted on the ceiling or wall. It is not a tabletop device. You must install this device on the ceiling or wall as outlined below. Read "Where to Install This Alarm" before starting.

CAUTION!


- Do not connect this unit to any other Alarm or auxiliary device. It is a single-station unit that cannot be linked to other devices. Connecting anything else to this unit may prevent it from working properly.
- Do not install this unit over an electrical junction box. Air currents around junction boxes can prevent smoke from reaching the sensing chamber and prevent the unit from alarming. Only AC powered units are intended for installation over junction boxes.

This unit is designed to be mounted on the ceiling, or on the wall if necessary.

Tools you will need: pencil, drill with 3/16" (5 mm) drill bit, standard flathead screwdriver, hammer

Parts of this Smoke/CO Alarm

- Battery compartment, install batteries here
- Test/Silence button
- CO Alarm LED
- Power/Smoke Alarm LED
- Turn this way to remove
- Turn this way to attach
- Mounting bracket
- Mounting slots



FOLLOW THESE SIMPLE STEPS

- Choose a location. See "Where to Install This Alarm" for reference. **WARNING! Do not install this Alarm over an existing electrical box. Only AC powered units are intended for installation over electrical boxes.**
- Hold base firmly and twist the mounting bracket counterclockwise (left) to separate it from the unit.
- Hold the mounting bracket against the ceiling (or wall) so the vertical mounting slot is aligned in the 12 o'clock position and trace around the inside of the mounting slots (vertical and horizontal mounting).
- Put the unit where it won't get covered with dust when you drill the mounting holes.
- Using a 3/16" (5 mm) drill bit, drill a hole through the center of the oval outlines you traced.
- Insert the plastic screw anchors (in the plastic bag with screws) into the holes. Tap the screw anchors gently with a hammer, if necessary, until they are flush with the ceiling or wall.
- Line the mounting bracket up over the plastic screw anchors.
- Screw the mounting bracket to the ceiling or wall through the mounting slots using the two screws provided.

Before attaching the Alarm to the bracket, insert the two (2) AA batteries (included) into the battery compartment. Match the terminals on the end of the battery with the terminals on the unit. Match "+" to "+" and "-" to "-" if the batteries are not fully inserted, the unit cannot receive battery power.

NOTE: The unit may beep briefly when you install the batteries. This is normal. The GREEN Light flashes about every 60 seconds when the unit is receiving battery power.

WARNING! The battery door will resist closing unless batteries are installed. This warns you the unit will not operate without batteries.

Attach the Smoke/CO Alarm to the mounting bracket. Line up the guides on the Alarm's base with the guides on the mounting bracket. When guides are lined up, turn the base clockwise (right) until it snaps into place.

NOTE: Once the Smoke/CO Alarm is snapped onto the mounting bracket, you can rotate the Smoke/CO Alarm to adjust the alignment.

Test the Smoke/CO Alarm. See "Weekly Testing" for details.

What You Will See & Hear

Under Normal Operations
Horn: Silent; Power/Smoke LED: Flash Green approx every 45 seconds; CO LED: Off

When You Test the Alarm
A "chirp" and then Horn: 3 beeps, pause, 3 beeps; Power/Smoke LED: Flashes Red in sync with horn; CO LED: Off; and then Horn: 4 beeps, pause, 4 beeps; Power/Smoke LED: Off; CO LED: Flashes Red in sync with horn

Battery Becomes Low
Horn: Chirp 1x approx every 45 seconds; Power/Smoke LED: Flashes Green in sync with horn; CO LED: Off

Low Battery Signal is Silenced (for up to 8 hours)
Horn: Silent; Power/Smoke LED: Flashes Green 1x approx every 45 seconds; CO LED: Off

Alarm is Not Operating Properly (Manufacturing Signal)
Horn: Chirp 5x approx every 45 seconds; Power/Smoke LED: Flashes Green in sync with horn; CO LED: Off

Alarm Has Reached End of Life
Horn: Chirp 5x approx every 45 seconds; Power/Smoke LED: Flashes Green in sync with horn; CO LED: Off

End of Life Signal is Silenced (for up to 2 days, 14 total)
Horn: Silent; Power/Smoke LED: Flashes Green 5x approx every 45 seconds; CO LED: Off

Smoke is Detected
Horn: 3 beeps, pause, 3 beeps, repeating; Power/Smoke LED: Flashes Red in sync with horn; CO LED: Off

Smoke Alarm is Silenced (for up to 15 minutes)
Horn: Silent; Power/Smoke LED: Flashes Red 3 times, pause, 3 times, repeating; CO LED: Off

Carbon Monoxide is Detected
Horn: 4 beeps, pause, 4 beeps; Power/Smoke LED: Off; CO LED: Flashes Red in sync with horn

CO Silence Signal (for up to 4 minutes)
Horn: Silent; Power/Smoke LED: Off; CO LED: Flashes Red in 4 times, pause, 4 times, repeating

04 ALARM FEATURES

- End-of-Life Warning:** Lets you know when it's time to replace.

OPTIONAL LOCKING FEATURES


The optional locking features are designed to discourage unauthorized removal of the batteries or Alarm. It is not necessary to activate the locks in single-family households where unauthorized battery or Alarm removal is not a concern.

Tools you will need: Needle-nose pliers or utility knife, standard flathead screwdriver

These Alarms have two separate locking features: one to lock the battery compartment, and the other to lock the Alarm to the mounting bracket. You can choose to use either feature independently, or use them both.

Both locking features use locking pins, which are milled into the mounting bracket. Depending on which locking features you use, remove one or both pins from the mounting bracket using needle-nose pliers or a utility knife.

IMPORTANT! To permanently remove either lock, insert a flathead screwdriver between the locking pin and the lock, and pry the pin out of the lock.



TO LOCK THE BATTERY COMPARTMENT

Do not lock the battery compartment until you activate the battery and the light features of the Smoke/CO Alarm.

- Push and hold Test/Silence button until the Alarm sounds.

IMPORTANT! If you do not lock the Alarm during testing, DO NOT lock the battery compartment! Install new batteries and test again. If the unit still does not Alarm, replace it immediately.

- Using needle-nose pliers or a utility knife, detach one locking pin from the mounting bracket.
- Push the locking pin through the hole near the battery door latch on the back of the Smoke/CO Alarm.

CO Alarm goes back into Alarm 4 minutes after you Silence it.
CO levels indicate a potentially dangerous situation.

CO Alarm sounds frequently even though no high levels of CO are revealed in an investigation.
The CO Alarm may be improperly located. Refer to "Where to Install This Alarm" for details.

CO Alarm sounds when no smoke is visible.
If you are feeling symptoms of CO poisoning, evacuate your home and call 911 or the Fire Department. Refer to "If the CO Alarm Sounds" for details.

CO Alarm may be silenced.
Relocate your Alarm. If frequent Alarms continue, have Alarm rechecked for potential CO problems. You may be experiencing an intermittent CO problem.

Smoke Alarm only
Silence Alarm using Test/Silence button; clean the Alarm's cover with a soft, clean cloth. If frequent unwanted alarms continue, relocate your Alarm. Alarm may be too close to a kitchen, cooking appliance, or steamy bathroom.

For a list of acceptable replacement batteries, see "Regular Maintenance."

If you have questions that cannot be answered by reading this manual, call the Consumer Support Team at 1-800-323-9005

TO UNLOCK THE BATTERY COMPARTMENT

- Remove the Smoke/CO Alarm from the mounting bracket. If the unit is locked to the bracket, see the section "To Unlock the Mounting Bracket."
- Insert a flathead screwdriver under the head of the locking pin, and gently pry it out of the battery compartment lock. (If you plan to relock the battery compartment, save the locking pin.)
- Remove the battery compartment, close the battery door and reinsert locking pin in lock.
- Reattach the Smoke/CO Alarm to the mounting bracket.

IMPORTANT! When replacing the batteries, always test the Alarm before relocking the battery compartment.

TO LOCK THE MOUNTING BRACKET

- Using needle-nose pliers or a utility knife, detach one locking pin from the mounting bracket.
- Insert the locking pin through the hole on the back of the Smoke/CO Alarm as shown in the diagram.
- When you attach the Smoke/CO Alarm to the mounting bracket the locking pin's head will fit into a notch on the bracket.

TO UNLOCK THE MOUNTING BRACKET

- Insert a flathead screwdriver between the mounting bracket pin and the mounting bracket.
- Pry the Alarm away from the bracket by turning both the screwdriver and the Alarm counterclockwise (left) at the same time.

WARNING! Activation of your CO Alarm indicates the presence of carbon monoxide (CO) which can kill you. In other words, when your CO Alarm sounds, you must not ignore it!

IF THE CO ALARM SIGNAL SOUNDS:

- Press the Test/Silence button.
- Call your emergency services, fire department or 911. Write down the number of your local emergency service here.

IF THE CO ALARM SIGNAL SOUNDS:

- Immediately move to fresh air—outdoors or by an open door or window. Do a head count to check that all persons are accounted for. Do not re-enter the premises, or move away from the open door or window until the emergency services responder has arrived, the premises have been aired out, and your CO Alarm remains in its normal condition.

IF THE CO ALARM SIGNAL SOUNDS:

- After following steps 1-3, if your CO Alarm reactivates within a 24-hour period, repeat steps 1-3 and call a qualified appliance technician to investigate for sources of CO from fuel-burning equipment and appliances, and inspect for proper operation of this equipment. If problems are identified during this inspection have the equipment serviced immediately. Note any combustion equipment not inspected by the technician, and consult the manufacturers' instructions, or contact the manufacturers directly, for more information about CO safety and this equipment. Make sure that motor vehicles are not, and have not, been operating in an attached garage or adjacent to the residence. Write down the number of a qualified appliance technician here.

NOTE: A qualified appliance technician is defined as "a person, firm, corporation, or company that is in person or through a representative, is engaged in and responsible for the installation, testing, servicing, or replacement of heating, ventilation, air conditioning (HVAC) equipment, combustion appliances and equipment, and/or gas fireplaces or other decorative combustion equipment."

IF THE SMOKE ALARMS ARE RESPONDING TO AN ALARM

WARNING!

- If the unit Alarms and you are not testing the unit, it is warning you of a potentially dangerous situation that requires your immediate attention. **NEVER** ignore any Alarm. Ignoring the Alarm may result in injury or death.
- Never remove the batteries from a battery operated Smoke/CO Alarm so that an unwanted Alarm (caused by cooking smoke, etc.) Removing batteries disables the Alarm so it cannot sense smoke, and removes your protection. Instead open a window or fan the smoke away from the unit. The Alarm will reset automatically.
- If the unit Alarms get everyone out of the home immediately.

WHAT TO DO IN CASE OF FIRE

- Don't panic, stay calm. Follow your family escape plan.
- Get out of the house as quickly as possible. Don't stop to get dressed or collect anything.
- Feel doors with the back of your hand before opening them. If a door is cool, open it slowly.
- Don't open a hot door. Keep doors and windows closed, unless you must escape through them.
- Cover your nose and mouth with a cloth (preferably damp). Take short, shallow breaths.
- Meet at your planned meeting place outside your home, and do a head count to make sure everybody got out safely.
- Call the Fire Department as soon as possible from outside. Give your address, then your name.
- Never go back inside a burning building for any reason.
- Contact your Fire Department for ideas on making your home safer.

WARNING! Always use the exact batteries specified by this User's Manual. Do not use rechargeable batteries. Clean the battery contacts and also those of the device prior to battery installation. Install batteries correctly with regard to polarity (+ and -).

Prevent disposal of or recycle used battery property, following any local regulations. Consult your waste management authority or recycling organization to find an electronics recycling facility in your area. **DO NOT DISPOSE OF BATTERIES IN FIRE. BATTERIES MAY EXPLODE OR LEAK.** Constant exposure to high or low temperatures or high humidity may reduce battery life.

WARNING! Keep battery out of reach of children. In the event a battery is swallowed, immediately contact your poison control center, your physician, or the National Battery Ingestion hotline at 202-625-3333 as serious injury may occur.

IMPORTANT! Specific model fire depends on the Smoke/CO Alarm and the environment in which it is installed. All the batteries specified above are acceptable replacement batteries for this unit. Regardless of the manufacturer's suggested battery life, you **MUST** replace the battery immediately once the unit starts "chirping" (the "low battery warning").

To replace the batteries (without removing Alarm from the ceiling or wall!):

- Open the battery compartment.
- Press tabs A and B as shown in the diagram and remove each battery.
- Insert the new batteries, making sure they snap completely into the battery compartment. Match the terminals on the ends of the batteries with the terminals on the unit.
- Close the battery compartment, and then test the unit by pressing the Test/Silence button.

When the Smoke Alarm is Silenced
The Smoke Alarm will remain silent for up to 15 minutes, then return to normal operation. If the smoke has not cleared—or continues to increase—the device will go back into Alarm.

When the CO Alarm is Silenced
The CO Alarm will remain silent for up to 4 minutes. After 4 minutes, if CO levels remain potentially dangerous the horn will start sounding again.

TROUBLESHOOTING GUIDE

IF THE ALARM... **PROBLEM...** **YOU SHOULD...**

Horn "chirps" about once per minute. Low battery warning. Install two new AA batteries*.

Horn does three "chirps" every minute; LED has 3 rapid flashes with "chirps". MALFUNCTION SIGNAL. Device is not working properly, and needs to be replaced. If unit is under warranty, contact Consumer Support to process a warranty replacement.

The light flashes GREEN. END OF LIFE SIGNAL. Alarm needs to be replaced. Immediately replace the Alarm.

CARBON MONOXIDE ALARM ONLY
CO Alarm goes back into Alarm 4 minutes after you Silence it. CO levels indicate a potentially dangerous situation. If you are feeling symptoms of CO poisoning, evacuate your home and call 911 or the Fire Department. Refer to "If the CO Alarm Sounds" for details.

CO Alarm sounds frequently even though no high levels of CO are revealed in an investigation. The CO Alarm may be improperly located. Refer to "Where to Install This Alarm" for details.

CO Alarm sounds when no smoke is visible. Unwanted Alarm may be caused by nonemergency source like cooking smoke. Relocate your Alarm. If frequent Alarms continue, have Alarm rechecked for potential CO problems. You may be experiencing an intermittent CO problem.

For a list of acceptable replacement batteries, see "Regular Maintenance."

If you have questions that cannot be answered by reading this manual, call the Consumer Support Team at 1-800-323-9005

SMOKE ALARM ONLY
Silence Alarm using Test/Silence button; clean the Alarm's cover with a soft, clean cloth. If frequent unwanted alarms continue, relocate your Alarm. Alarm may be too close to a kitchen, cooking appliance, or steamy bathroom.

For a list of acceptable replacement batteries, see "Regular Maintenance."

If you have questions that cannot be answered by reading this manual, call the Consumer Support Team at 1-800-323-9005

FIRE SAFETY TIPS
Follow safety rules and prevent hazardous situations: 1) Use smoking materials properly. Never smoke in bed. 2) Keep matches or lighters away from children. 3) Store flammable materials in proper containers; 4) Keep electrical appliances in good condition and don't overload electrical circuits; 5) Keep stoves, barbecue grills, fireplaces and chimneys grease- and debris-free; 6) Never leave anything cooking on the stove unattended; 7) Keep portable heaters and open flames, like candles, away from flammable materials; 8) Don't let rubbish accumulate. Keep Alarms clean, and test them weekly. Replace Alarms immediately if they are not working properly. Smoke Alarms that do not work cannot alert you to a fire. Keep at least one working fire extinguisher on every level, and an additional one in the kitchen. Have fire escape ladders or other reliable means of escape from an upper level in case stairs are blocked; 9) Have an escape plan and practice it regularly.

06 IF YOUR SMOKE/CO ALARM SOUNDS

WHAT TO DO FIRST—IDENTIFY THE TYPE OF ALARM SIGNAL

Type of Alarm	What You See and Hear
Carbon Monoxide (CO)	CO LED: Flashes Red; Horn: 4 beeps, pause, 4 beeps, pause; Power/Smoke LED: Off
Smoke	Power/Smoke LED: Flashes Red; Horn: 3 beeps, pause, 3 beeps, pause; CO LED: Off

IF THE CO ALARM SOUNDS

"ALARM MOVE TO FRESH AIR"
If you hear the CO Alarm horn and the CO red light is flashing, move everyone to a source of fresh air. **DO NOT REMOVE the batteries!**

WARNING! Activation of your CO Alarm indicates the presence of carbon monoxide (CO) which can kill you. In other words, when your CO Alarm sounds, you must not ignore it!

IF THE CO ALARM SIGNAL SOUNDS:

- Press the Test/Silence button.
- Call your emergency services, fire department or 911. Write down the number of your local emergency service here.

IF THE CO ALARM SIGNAL SOUNDS:

- Immediately move to fresh air—outdoors or by an open door or window. Do a head count to check that all persons are accounted for. Do not re-enter the premises, or move away from the open door or window until the emergency services responder has arrived, the premises have been aired out, and your CO Alarm remains in its normal condition.

IF THE CO ALARM SIGNAL SOUNDS:

- After following steps 1-3, if your CO Alarm reactivates within a 24-hour period, repeat steps 1-3 and call a qualified appliance technician to investigate for sources of CO from fuel-burning equipment and appliances, and inspect for proper operation of this equipment. If problems are identified during this inspection have the equipment serviced immediately. Note any combustion equipment not inspected by the technician, and consult the manufacturers' instructions, or contact the manufacturers directly, for more information about CO safety and this equipment. Make sure that motor vehicles are not, and have not, been operating in an attached garage or adjacent to the residence. Write down the number of a qualified appliance technician here.

NOTE: A qualified appliance technician is defined as "a person, firm, corporation, or company that is in person or through a representative, is engaged in and responsible for the installation, testing, servicing, or replacement of heating, ventilation, air conditioning (HVAC) equipment, combustion appliances and equipment, and/or gas fireplaces or other decorative combustion equipment."

This Smoke/CO Alarm may not sense smoke or CO on another level of the home. Example:

This Alarm device, installed on the second floor, may not sense smoke or CO in the basement. For this reason, one Alarm device may not give adequate early warning. Recommended minimum protection is one Alarm device in every sleeping area, every bedroom, and on every level of your home. Some experts recommend battery powered smoke and CO Alarms be used in conjunction with interconnected AC powered Smoke Alarms. For details, see "About Smoke Alarms" for details.

Smoke/CO Alarms may not be heard. The Alarm horn loudness meets or exceeds current UL standards of 85 dB at 10 feet (3 meters). However, if the Smoke/CO Alarm is installed outside the bedroom, it may not wake up a sound sleeper or one who has recently used drugs or has been drinking alcoholic beverages. This is especially true if the door is closed or only partly open. Even persons who are awake may not hear the Alarm horn if the sound is blocked by distance or closed doors. Noise from traffic, stereo, radio, television, air conditioner, or other appliances may also prevent alert persons from hearing the Alarm horn. This Smoke/CO Alarm is not intended for people who are hearing impaired.

The Alarm may not have time to Alarm before the fire itself causes damage, injury, or death, since smoke from some fires may not reach the unit immediately. Examples of this include **persons smoking in bed, children playing with matches, when a person's clothing catches fire while cooking, fires caused by violent explosions resulting from escaping gas, or incendiary fires where the fire grows so rapidly that an occupant's egress is blocked even with properly located Smoke Alarms.**

This Smoke/CO Alarm is not a substitute for life insurance. Though this Smoke/CO Alarm warns against increasing CO levels or the presence of smoke, First Alert does not warrant or imply in any way that they will protect lives. Homeowners and renters must still insure their lives.

This Smoke/CO Alarm has a limited life. Although this Smoke/CO Alarm and all of its parts have passed many stringent tests and are designed to be as reliable as possible, any of these parts could fail at any time. Therefore, you must test this device weekly. The unit should be replaced immediately if it is not operating properly.

This Smoke/CO Alarm is not foolproof. Like all other electronic devices, this Smoke/CO Alarm has limitations. It can only detect smoke or CO that reaches the sensors. It may not give early warning of the source of smoke or CO is in a remote part of the home, away from the Alarm device.

15 LIMITED WARRANTY

First Alert® brand products warrants that for a period of ten years from the date of purchase, this product will be free from defects in material and workmanship. First Alert, at its option, will repair or replace this product or any component of the product found to be defective during the warranty period. Replacement will be made with a new or remanufactured product or component. If the product is no longer available, replacement may be made with a similar product of equal or greater value. This is your exclusive warranty.

This warranty is valid for the original retail purchaser from the date of initial retail purchase and is not transferable. Keep the original sales receipt. Proof of purchase is required to obtain warranty performance. First Alert dealers, service centers, or retail stores selling First Alert products do not have the right to alter, modify or any way change the terms and conditions of this warranty.

This warranty does not cover normal wear or parts or damage resulting from any of the following: negligent use or misuse of the product, use on improper voltage or current, use contrary to the operating instructions, disassembly, repair or alteration by anyone other than First Alert or an authorized service center. Further, the warranty does not cover Acts of God, such as fire, flood, hurricanes and tornadoes or any batteries that are included with this unit.

First Alert shall not be liable for any incidental or consequential damages caused by the breach of any express or implied warranty. Except to the extent prohibited by applicable law, any implied warranty of merchantability or fitness for a particular purpose is limited in duration to the duration of the above warranty. Some states, provinces or jurisdictions do not allow the exclusion or limitation of incidental or consequential damages or limitations on how long an implied warranty lasts, so the above limitations or exclusion may not apply to you. This warranty gives you specific legal rights, and you may also have other rights that vary from state to state or province to province.

HOW TO OBTAIN WARRANTY SERVICE

Service: If service is required, do not return the product to your retailer. In order to obtain warranty service, contact the Consumer Support Team at 1-800-323-9005. To assist us in serving you, please have the model number and date of purchase available when calling.

Battery: First Alert make no warranty, express or implied, written or oral, including that of merchantability or fitness for any particular purpose with respect to battery.

Disposal: Please follow local guidelines regarding the disposal or recycling of batteries and/or electronics.

For your records, please record:
Date Purchased: _____
Where Purchased: _____
Date Installed: _____ / _____ Month/Year
Replace Alarm 10 years after installation.
Please write the date in the space provided: _____ / _____ Month/Year

The Alarm will also provide an audible End-of-Life Signal approximately 10 years after installation to remind you to replace the unit.

The End-of-Life Signal can be silenced for up to 2 days. Do not unplug the Alarm or remove the batteries until you get replacement.

Printed in Mexico | M08-0605-000 03/23

CONFORMS TO UL STD 217 AND UL STD 2034

firstalert.com



© 2023 Resideo Technologies, Inc. All rights reserved. These products are manufactured by Resideo Technologies, Inc. and its affiliates. 3901 Liberty Street, Aurora, IL 60504-8122. Consumer Support Team: (800) 323-9005 | firstalert.com